


# Massivit 10000

## Sales Kit Information

3D Printing Technology: Cast-In-Motion (CIM)

Milling/ polish orientation



Planar surfaces



Bushings used for accuracy in the milling process

Implant bushings


Printing orientation



Planar surfaces

Parallel grip areas for milling process

Dedicated technical datums for mounting on process cart




Trimming line



Carbon skin




Hot air passages.  
Uniform heating of mold.



Print flow design.  
Easy to print,  
easy to cast.

Extra casting if needed



# Massivit 10000

## Useful Information

---

### Mold for Carbon Fiber Lamination

---

#### Workflow

CAD → SMART Slicer → Printer → Oven → Water tank → Milling/Polish → Laminate

---

#### Part Dimensions

- **X:375mm, Y:200mm, Z:65mm**
- **X:14-inch, Y:7.87-inch, Z:2.56-inch**
- Skin material: carbon fiber with epoxy resin
- Trim line in CNC

#### Mold Information

- Print time: 01:56 hrs.
- Printing material: Dimengel Water Breakable (DIM WB)
- Print layer thickness: 1 mm/0.0394-inch height
- Wall thickness: 3.6 mm/0.14184-inch width
- Printing material weight: 900g/1.9845 lb.
- Casting material weight: 3kg/6.615lb .
- Immersion time of mold in water for walls to crumble:  
~8hrs