



Massivit M1000

Composite Lay-up tool Time and Material Estimate


Confidential and Proprietary. Copyright (c) Massivit 3D. All Rights Reserved.



Adjusted a model


Adjustment was preformed to the part to accommodate a maximum thickness of 25 mm, this is to avoid high exothermal reaction during printing, by doing so we save casting material & reduced tool wight. Additionally, having a unified thickness will aid with heat transfer in an autoclave process.

Original Part




6.70 US gallon

Adjusted Part




4.40 US gallon

Size & dimensions




Details

Part:	Layer Thickness:	Casting cure material	Printing shell Material (Washable)	Total weight (Out of the printer)	Print time	Total weight (after shell removal)
L Lower V2 M10K	1 mm	17 Kg	7.8 Kg	24.8 Kg	21:32 hours	17 Kg



Printing orientation

Printing orientation:
Orientating the part standing on end ensures the best surface quality for the mold surface.



STL file

Tool path

Thank You



Confidential and Proprietary. Copyright (c) Massivit 3D. All Rights Reserved.